

RESCUE® Concentrate: 5 Gallon Pail

QUICKSTART GUIDE

Components



Extension tubing



Rescue Concentrate: 5 Gallon Pail

How to use Rescue™ Concentrate Pail with a dispensing pump



STEP 1 Pull up the flexspout on your Rescue pail, and remove the yellow cap. Wearing gloves, remove the seal.



STEP 2 Screw the pail adaptor onto the flexspout, until it is fitted tightly to the base of the pail.



STEP 3 Insert the extension tubing onto the outlet on the bottom of the pump. Although extension tubing is provided, only one single tube is required due to the size of the pail.



STEP 4 Insert the pump into the pail, and screw into the pail adaptor until tight.



Concentrate: 5 Gallon Pail

QUICKSTART GUIDE



STEP 5 Prime the pump by moving the handle up and down until Rescue Concentrate is drawn out.

Use a bucket or large container to catch any concentrate.

If you need to discard the concentrate, dilute the concentrate with water, then pour the diluted product slowly down the drain with running water.



STEP 6 Add the snap-on volume adaptors provided to adjust the pump delivery volume.

- •For a 1:16 dilution, do not use any adaptors. Each pump should deliver 8 oz. of concentrate (to add to 1 Gallon of water).
- •For a **1:64 dilution**, use **both the large and small adaptors** provided. Each pump should deliver **2 oz. of concentrate** (to add to 1 Gallon of water).

Use a measuring cup to confirm that the correct volume is dispensed.

Troubleshooting Tip

Product isn't coming out of the pump

It may take longer than expected to prime the pump especially if you need to re-prime the pump. Remove the snap-on adaptors and move the handle up and down until concentrate is drawn out.

Desired Dilution Ratio	Amount of Rescue Concentrate to add to 32 02 OF WATER (ex: Spray Bottle)	Amount of Rescue Concentrate to add to 1 GALLON OF WATER (ex: Pail)	Amount of Rescue Concentrate to add to 5 GALLONS OF WATER (ex: Mop Bucket)
1:16	2 oz	8 oz	40 oz
1:32	1 oz	4 oz	20 oz
1:64	0.5 oz	2 oz	10 oz
1:128	0.25 oz	1 oz	5 oz

For more resources visit LearnAboutRescue.com







RESCUE° Rescue™ is a member of the Virox family of brands.

Refer to product label and reference sheet for full list of claims, contact times and use-directions.

Warning: You must read and follow the instructions on the label for our product and use the product for the particular applications spec-ified on the product label. To the full extent permitted under applicable law, Virox Technologies Inc. shall not be liable for any damages whatsoever, arising out of or otherwise in connection with any failure to follow those instructions or any use of its products which is not specified on the product's label. The instructions on the product label are not a warranty, express or implied, and Virox Technologies, Inc. expressly disclaims any implied warranties, including any warranty of fitness for a particular purpose. Under applicable law, some of the above waivers or disclaimers of warranty, or exclusions of liability for certain types of damages may not apply to you. In such cases, our liability will be limited to the fullest extent permitted by applicable law.

AHP® and Design and Accelerated Hydrogen Peroxide® and Design are trademarks of Diversey, Inc.